


Shower Panel with Double Entry



www.merlynshowering.com

MERLYN

Merlyn Showering
Unit 8, Purcellsinch Industrial Park,
Dublin Road, Kilkenny, Ireland.
Tel: 00353 56 779 1555
Fax: 00353 56 779 1576
www.merlynshowering.com

To download the Declaration of Performance (DOP) for
this product please use the link below.
<https://merlynshowering.com/aftersales-support/dop-certs/>

INSTALLATION GUIDE

IMPORTANT: Please read the complete instructions before commencing fitting.

Make sure the tray is 100% level in all directions.

Check that you have the tools required.□

Check the installation site is compatible with the sizes of door supplied.□

Check all the enclosure components are present.□



Check the installation kit is complete.□

Do Not attempt to install the product unless you can tick all 4 boxes satisfactory.





The wall plugs supplied with the installation kit are for use in solid walls. Hollow or 'stud partition' walls will require alternative fixings. Please consult a hardware supplier for the correct type.

ATTENTION: TAKE EXTREME CARE WHEN HANDLING GLASS, WEAR PROTECTIVE EYEWEAR AND CLOTHING. DO NOT LEAVE THE GLASS ON HARD SURFACES AND AVOID CONTACT BETWEEN THE GLASS EDGES AND HARD SURFACES OR IMPACTS DURING THE INSTALLATION.

Fixing kit components




Tools required



PH2

Ø6&Ø8



No.	QTY	Descriptions	Part No.	No.	QTY	Descriptions	Part No.
①	2	Grubscrew	S8GRBSC	⑤	1	Bottom profile	MGVC35
②	2	Screw 4x30	MGST4x30BH	⑥	2	Wall plug 6x30	MG6x30PLUG
③	2	Support rail	S8TRSET	⑦	2	Wall bracket	S8RAWBR
④	1	Shower wall panel	GMGWD	⑧	2	Grubscrew	M8x6GNLT

Attention: Bottom profile MGVC35 is cut to suit 1600 shower wall. For 1400 shower wall the profile needs to be cut to 1380mm.




Step 1

Remove the protective strip from the vase of base of the bottom profile and place the bottom profile in the desired position. Max distance 'X' shower wall can be fitted from back wall is 1020mm.




Attention: 3M adhesive tape is single use only. You will have just 1 attempt to fit profile.



Step 2


Note which side is labeled OUTSIDE. Place glass panel into bottom profile ensuring the edge of the glass is flush with the end of the profile.



Ensuring the edge of the glass is flush with the end of the profile!

Step 3

Level the rail and mark the position of the bracket on the wall, then mark the fixing point.



Step 4

