



Installation Guide One door quadrant

Left hand



Right hand



IMPORTANT:
**Please read the complete instructions
before commencing fitting.**

Make sure the tray is 100% level in all directions.


Do Not attempt to install the product unless you can tick all 4 boxes satisfactory.

- **Check that you have the tools required**
- **Check the installation site is compatible with the sizes of door supplied**
- **Check all the enclosure components are present**
- **Check the installation kit is complete**

The wall plugs supplied with the installation kit are for use in solid walls. Hollow or 'stud partition' walls will require alternative fixings. Please consult a hardware supplier for the correct type.

It may also be necessary to consult your tiling supplier about the correct method for drilling tiles.






ATTENTION: TAKE EXTREME CARE WHEN HANDLING GLASS, WEAR PROTECTIVE EYEWEAR AND CLOTHING. DO NOT LEAVE THE GLASS ON HARD SURFACES AND AVOID CONTACT BETWEEN THE GLASS EDGES AND HARD SURFACES OR IMPACTS DURING THE INSTALLATION.




No.	QTY	Description	Code	No.	QTY	Description	Code
01	1	Top cap for adjusting profile, left	A6UPPCAPL	13	1	Top cap for adjusting profile, right	A6UPPCAPR
02	1	Top cap for wall profile, left	A6WPCAPL	14	1	Upright seal for one door quad	A61DQUPS
03	2	Wall profile	A6STDWP	15	1	One door quad roller, Top right	A61DQROLTR
04	8	Wall plug	A6WPLUG	16	1	Sliding door/ 1 door quad roller, Top left	A6SLROLTL
05	10	Frame fixing screw	A64X8FRA	17	1	Upright water seal 15mm for 1 door quadrant moving	AR1QUPSM
06	8	Pan head wall screw	A6WSCRW	18	1	Upright water seal 15mm for 1 door quadrant fixed	AR1QUPSF
07	2	U shape bottom seal	A6SLFIXPS	19	2	Profile filler piece	A6PROFILL
08	1	Sliding door/ 1 door quad roller, Bottom left	A6SLROLBL	20	2	Cover strip	A6STDCS
09	1	One door quad roller, Bottom right	A61DQROLBR	21	1	Fixed panel	
10	1	Handle	A6HANDLE	22	1	Moving door	
11	1	Top cap for wall profile, right	A6WPCAPR	23	1	Flat fixed panel	
12	2	One door quad Top/bottom rail	A61DQTBP*				

*Please note that the top and bottom profile code will change depending on enclosure size. For example- 900mm= A691DQTBP

Fixing Kit Components

						
A6SLROTL	A61DQROLTR	A6SLROLBL	A61DQROLBR	A6PROFILL	AR6SPACER1 1&1.5mm	AR6SPACER2 2&3mm
x1	x1	x1	x1	x1	x1	x1
						
A64X8FRA ST4*8	A6WSCRW ST4*30	A6WPLUG Ø6	A6UPPCAPL	A6UPPCAPR	A6WPCAPL	A6WPCAPR
x10	x8	x8	x1	x1	x1	x1
						
Ø3	A6HANDLE	2.5mm				
x1	x1	x1				


Tools required



1

Ensure the shower tray is level in all directions and is properly sealed to the wall. The wall must be tiled down to the top edge of the tray. Do not angle out bottom tile.


TRAY MUST BE LEVEL IN ALL DIRECTIONS!
TRAY MUST BE SEALED FULLY IN ALL AREAS WHERE THE TRAY MEETS THE WALL.






2

Note: This is a handed product but is shown in left hand configuration for illustration purposes.




Size	X	Y
(900 x 760)	855-880	715-740
(1000 x 800)	955-980	755-780
(1200 x 800)	1155-1180	755-780
(900 x 900)	855-880	855-880
(1000 x 1000)	955-980	955-980
(1200 x 900)	1155-1180	855-880



3




4





5

5A






5B



6


Push the seal onto the fixed panel making sure it is 10mm from the edge.
NOTE: After step 9 make sure seal is still in the same position.






9


9A





9C



9B




9D





10




10A








10B



11




12





13

Where possible the frame should be adjusted equally on both sides, $A=B$.
Max. adjustment of each side (A&B) is **25mm**.








14

Make sure the bottom profile is level. If level continue to step 15. If not level choose a spacer size from AR6SPACER1/A6SPACER2 that returns the profile to level.







15

15A ,15C From inside drill the frame top, middle and bottom making sure to step in a Min. 15mm from the edge of the frame.
15B,15D On Max. adjustment drill 4mm from the edge of the frame as shown below.




16



17


After the handing has been determined fix the rollers to the moving panel as shown in 17A. Note: Please check the roller labeling for correct orientation.

17A




17B

TOP ROLLERS ASSEMBLY




17C

BOTTOM ROLLERS ASSEMBLY




18

18A




18B

PUSH





18C






18D







RELEASE






19



20





2.5mm





21

Adjust the rollers to plumb the moving panel. Also ensure the bottom rollers are in contact with the profile.




22

There should be no gap between both roller arms and the roller stops. Adjust rollers up or down to allow for full insertion.





23







23A



23B



24



CLEANING

It is important to clean your Merlyn shower door after every use. Wipe down all the glass and metal parts with a soft cloth. Do not allow lime scale to build up in hard water areas. Ensure that any residual water on the glass is removed after every use.

- Clean the glass regularly using soapy water.
- Do not use abrasive products on any surfaces.

Chrome is vulnerable to acid attack and some strong household cleaners including strong disinfectants, denture cleaners, hair dyes, wine making chemicals and photographic chemicals may contain acid. These materials may have a varying effect on the surface from black spots/streaks (which cannot be removed) to pitting the surface. Contact with these materials should be avoided.

TROUBLE SHOOTING

Door Not Aligning

1. Is the tray 100% level? (see page 5)
2. Have the walls been checked at different levels to ensure consistency? Bumps or hollows in the wall may push the frame out of alignment.
3. Are the wall profiles stepped in a Min. 10mm from the edge of the tray? (see step 3,4)
4. Do the finished tile measurements at top, middle and bottom fall within the adjustment (X) listed on step 2.
5. Are the rollers adjusted so the bottom rollers are running along the track in the frame and not rattling in the bottom track (see step 21)
6. Are the rollers adjusted so the closing side roller arm goes fully into the roller stop (see step 22).
7. If bottom roller easy clean function does not work correctly slightly loosen the screws on the top rollers (see step 21).

Door Leaking

1. This door is fitted with a soft close roller stop. Make sure the door is fully closed (see step 22). To ensure the best performance of the soft close periodical cleaning of the stop with a damp cloth may be required.
2. Are the rollers adjusted so the closing side roller arm goes fully into the roller stop on the top and bottom ? (see step 22)
3. Are the upright seals fitted correctly (see step 19)
4. Is the door sealed correctly ? (see step 24)
5. Have the fixed panels been properly secured? (See step 15)
6. Ensure a sufficient dab of silicone is applied between fixed clip and glass on bottom profile and upright seal is fitted to fixed panel. Then remove excess silicone. (See step 24)
7. Check to ensure the door frame is 100% square.

	
Merlyn Industrles Ltd (MER01)	
CEAR6 1.1	
18	
EN 14428	
Shower enclosures with aluminium profiles and safety glass	
Cleanability	: Pass
Impact resistance/ shatter propertles	: Pass
Durablily	: Pass

To download the Declaration of Performance (DOP) for this product use the link below.

<http://merlynshowering.com/aftersales-support/dop-certs/>

For further information contact IRL: 056 7791 888, UK: 0808 1011 429